

Lubrication system

Lubrication is necessary for proper maintenance of a motor vehicle. The main parts lubricated are (i) cylinder walls
(ii) crankshaft main bearing (iii) bearing of connecting rod etc.

Purpose :-


- (i) To reduce friction between the moving parts
- (ii) To reduce wear and tear of the moving parts.
- (iii) To cool the surface of piston, engine valves,

Types

(i) Petrol System

(ii) Splash System

(iii) Forced Lubrication



- > Oil pump is used to store oil
 - > Pump is used to pump the oil [full pressure lubrication]
 - > Lubrication is done by the holes in the bearings of crankshaft
- Connecting rod: